

Using Voicemail Control Features

While you listen to your messages...	Press	
Decrease message speed	7	
Increase message speed	9	
Decrease volume of messages and prompts	8	
Increase volume of messages and prompts	5	
Help	0	
Override message header in progress and proceed directly to message	3	
Skip backward from message header in progress to previous header	7 2	
Skip forward from message header in progress to the next header	2	
Stop a message and:	<i>skip forward</i> to the next message header.	* 2
	<i>resume listening</i> to it.	* 3
	<i>save</i> it.	* 4
	<i>delete</i> it.	* 6
	<i>skip backward</i> to the previous message header.	* 7 2
	<i>replay</i> it from the beginning.	* 7 3
	<i>end</i> the PhoneMail session.	* 7 6
	<i>replay the message header</i> with the time the message was created and received in your mailbox.	* 7 7
	<i>replay</i> the previous few words.	* 7 8
	<i>return</i> to home state.	* 7 #
	<i>skip</i> to the next message queue.	* 9 1
	<i>skip forward</i> to the end of the message.	* 9 3
<i>skip forward</i> a few words.	* 9 8	